
INSTALLATION INSTRUCTIONS

These wallcoverings are Digitally printed every effort is made to ensure consistency, minor variations in color, texture, and detail are inherent to the process and should be expected. These variations contribute to the unique character of each piece. Final inspection is the sole responsibility of the installer.

IMPORTANT: NO CLAIMS for cut merchandise or labor will be accepted, even if the wallcovering is deemed defective. The installer **MUST** examine the wallcovering thoroughly after every few strips to ensure the desired aesthetic is achieved.

I. Pre-Installation Checks

Before cutting any material, several crucial checks must be performed. First, verify the pattern name, number, and color match the order, ensuring sufficient material is available. Carefully inspect each roll for any shipping damage or obvious defects, checking for consistent appearance across all rolls. If you have any questions or concerns, contact your Koroseal representative before proceeding. Do not cut the material. Once the material is cut, no returns will be accepted.

II. Wall Preparation

Proper wall preparation is essential for a successful installation. All previous wallcovering must be completely removed. Walls must be structurally sound, smooth, dry, clean, and free from any imperfections or contaminants that could show through the finished surface. Prime the wall surface with a high-quality acrylic wallcovering primer specifically designed for delicate wallcoverings. Koroseal recommends Romans Pro 999 or 935. Allow the primer to dry completely according to the manufacturer's instructions. Consult a professional if necessary.

III. Trimming

Digital printed foil wallcoverings are shipped untrimmed. Carefully dry trim the selvage edges of each sheet. Ensure cuts are straight, clean, and parallel. Use a fresh blade for each cut. Each shipment contains bolts marked with consecutive numbers. Install the wallcovering in the order the bolts were produced (e.g., first strip from bolt 1, then second strip from bolt 1, etc.). This ensures the most consistent appearance across the wall.

IV. Adhesive

Use a heavy-duty clear vinyl wallcovering adhesive with a low water content. Koroseal recommends Romans Pro 838 or 234 Do not dilute. Before full installation, test the adhesive's compatibility with the wall surface and the wallcovering in an inconspicuous area.

V. Test Hanging

Before proceeding with the full installation, test hang three strips/panels. Carefully review the material, the application technique, and the overall appearance. If satisfactory, obtain approval from the end-user before continuing. If you are not satisfied, stop the installation and contact your Koroseal representative immediately. The manufacturer assumes no responsibility for installation beyond the initial three test strips. Under no circumstances will the manufacturer be responsible for labor costs. This is an industry standard.

VI. Installation

Foils and Digital printed Foils wallcoverings should only be installed by experienced, qualified wallcovering installers familiar with handling delicate materials. All trimming must be done dry on a clean, flat surface. Apply an even coat of adhesive to the back of the wallcovering using a ½" nap roller. Allow the pasted material to "book" (rest) for the time recommended by the adhesive manufacturer. Do not allow adhesive to contact the face of the wallcovering. Apply the material to the wall using a soft smoothing brush or a plastic smoother wrapped in a microfiber cloth. Use a seam roller to carefully close the seams. For Digital Print Foil there is a 1 inch bleed on the seam sides of the pattern creating a 2 inch over lap for double cutting the seam. To prevent paste getting on the face of the foil wallpaper use 2 inch blue masking tape. While pasting the back of the material before booking the sheet (folding) stick the tacky side of the blue masking tape to the paste along the edge of the sheet on the seam side. (If you're hanging right to left put tape on right side or visa Vera) then book your sheet (fold). Overlap and line up your pattern from top to bottom then lay sheet down from the seam side over to the other end. Double cut your seam using a #9 single edge razor blade and straight edge. For Foil you can butt or use the double cut method for your seams. Frequently clean your tools (smoothing brush, seam roller, etc.) to prevent paste buildup, which can mark or scratch the delicate surface. Thoroughly clean any adhesive residue from the surface of the wallcovering after each strip is hung. Use a damp sponge and clean, warm water. Drying off with a microfiber cloth. Change the rinse water frequently. Do not use excessive force or scrubbing. Dry the wallcovering carefully with a soft, microfiber cloth.

VII. Care and Maintenance

Wipe stains immediately with a clean, damp sponge or microfiber cloth. Use a mild, non-abrasive detergent if necessary. Do not use harsh chemicals, solvents, or abrasive cleaners. Do not soak the wallcovering. Avoid excessive rubbing or pressure, as this can damage the delicate finish.